

HOW TO SAFELY CLEAN THE KIOSK TOUCHSCREEN

- » Safely power down the kiosk then disconnect the power cable
- » Select only non-abrasive cleaning cloths to avoid scratching touchscreens
- » Do not get liquids inside the unit. If liquids get inside the unit, have a qualified technician determine whether it is safe to power the unit back on
- » Avoid highly concentrated (70%+) alcohol, bleach or ammonia solutions, as these may cause discoloration
- » Wipe the surfaces with the appropriate cloths and allow them to dry
- » Be sure to rinse your hands after handling any cleaning solutions



DISINFECTING PROCEDURE FOR TOUCHSCREEN AND PERIPHERALS

- » Dampen a clean, non-abrasive cloth with a disinfectant. Ensure excess moisture is squeezed from the cloth or use recommended pre-dampened wipes
- » Clean the surfaces and allow them to dry
- » Disinfect the surfaces and allow them to dry
- » Be sure to rinse your hands after handling any cleaning solutions

HOW TO CLEAN THE KIOSK INTERIOR

- » Do not use a vacuum to clean dust off your kiosk components. This can create a static buildup and could potentially damage important electrical components
- » We recommend using compressed air in order to remove dust and dirt from the kiosk's interior
- » When cleaning with compressed air place the hose near (but not touching) your kiosk components

US CDC-RECOMMENDED DISINFECTANT SOLUTIONS SAFE FOR USE

- » Use these on your millwork surfaces, countertops, and kiosk furniture enclosures
- » Household bleach solution (1/3 cup bleach **per gallon of water**)
- » Isopropyl alcohol (70% solution)

US EPA-RECOMMENDED DISINFECTANTS SAFE FOR USE

- » Clorox Disinfecting Wipes
- » Lysol Brand Clean & Fresh Multi Surface Cleaner (20% cleaner solution to water ratio)